

2.2. Charging the battery

Before operating your vehicle for the first time, fully charge the battery.

To charge the battery, plug the charger into the socket on the down tube. You can expose the socket by rotating the plastic cover. The charging time of a completely empty battery is about 4.5 hours.



The LED of the power button gives the following information when charging

flashes red →

battery is charging

flashes blue →

battery is fully charged



You can interrupt charging at any time by disconnecting the charger. The charger switches off automatically when the battery is fully charged.



The charger is not protected against moisture.
→ Only charge the battery in a dry interior.



Do not charge the pedelec near an open fire or in direct sunlight. This can lead to a short circuit of the internal protective function.

2.3. Switching the drive on/off

To switch on the bike, press briefly on the button on the top left of the down tube. The system switches on and the LED shows the battery charge level. To switch off, press the button for about 3s. The display power switch is disabled and turning on and off is only feasible through the button on the downtube.



LED flashes red →

battery: 0%-10% charged

LED lights up 5s red →

battery: 11%-30% charged

LED lights up 5s blue →

battery: 31%-100% charged